


Monteringsanvisning



		L	L1	L2	L3	L4
	AL/0005-...	1250				
		2500		250	125	
		5000	125			250
	AL/0009-...	2500		150	125	
		5000				
	AL/00 11-...	1250	25			
		2500	50	200	125	250
		5000	100			

